

Creating a VPC Peering Connection

Step 1: Creating a VPC Peering Connection

1. In the **AWS Management Console**, on the **Services** menu, choose **VPC**.
2. In the left navigation pane, choose **Peering Connections**.
3. Choose **Create Peering Connection** and configure:
 - **Peering connection name tag:** *Lab-Peer*
 - **VPC (Requester):** *Lab VPC*
 - **VPC (Acceptor):** *Shared VPC*
 - Choose **Create Peering Connection** then choose **OK**
4. Select **Lab-Peer**.
5. Choose **Actions** then select **Accept Request**, and choose **Yes, Accept** to accept the request.
6. In the pop-up box, choose **Close**.

Step 2: Configuring route tables

7. In the left navigation pane, choose **Route Tables**.
8. Select **Lab Public Route Table** (for *Lab VPC*).
9. In the **Routes** tab, choose **Edit routes** then configure these settings:

 - Choose **Add route**
 - **Destination:** *10.5.0.0/16* (The setting is the Classless Inter-Domain Route, or CIDR, block range of *Shared VPC*.)
 - **Target:** Select **Peering Connection**, and then from the list, select *Lab-Peer*.
 - Choose **Save routes** then choose **Close**.
10. You will now configure the reverse flow for traffic that comes from *Shared VPC* and goes to *Lab VPC*.
11. Select **Shared-VPC Route Table**. If the check boxes for any other route tables are selected, clear them.

This route table is for *Shared VPC*. You will now configure it to send traffic to the peering connection if the destination IP address falls in the range of *Lab VPC*.
12. In the **Routes** tab, choose **Edit routes** then configure these settings:
 - Choose **Add route**
 - **Destination:** *10.0.0.0/16* (This setting is the CIDR block range of *Lab VPC*.)
 - **Target:** Select *Peering Connection*, and then from the list, select *Lab-Peer*.
 - Choose **Save routes** then choose **Close**.
13. The route tables are now configured to send traffic via the peering connection when the traffic is destined for the other VPC.

Step 3: Testing the VPC peering connection.

14. On the **Services** menu, choose **EC2**.

15. In the left navigation pane, choose **Instances**.
16. Copy the **IPv4 Public IP** address that is shown in the **Description** tab.
17. Open a new web browser tab with that IP address. You should see the Inventory application and the following message: *"Please configure settings to connect to database"*
18. Choose **Settings** and configure:
 - **Endpoint:** Paste the database endpoint.
 - **Database:** inventory
 - **Username:** admin
 - **Password:** lab-password
 - Choose **Save**
19. The application should now show data from the database. This step confirms that the VPC peering connection was established because *Shared VPC* does not have an internet gateway. The only way to access the database is through the VPC peering connection.